

# Downtown Surge Classroom – Design Thinking

The display for this space is a projector and manual screen.

## Controlling the system with your Device

### 1. Connect to the project via HDMI cord

Turn the projector on using the NEC remote (normally located on the instructor's station)

### 2. Connect the Avaya Camera

Locate the USB cable connection and connect it to your device.

**MacBook:** If your computer does not have the appropriate USB port you will need to use an adapter. Connecting the USB web camera into a hub or docking station will not work.

### 3. Select Avaya HC020 as the camera and microphone source

In your chosen video conferencing interface (Zoom, WebEx, or Teams) select Avaya HC020 as the camera and microphone source.

**Note:** The Avaya remote can be used to adjust the camera (left, right, zoom in, zoom out).

If the camera does not respond to input from the remote

- Make sure the camera is on by looking for the blue light (this tiny light will be located beside the camera's lens)
- Press the "1" button on the remote
- Try the input again
- Note that if the camera has reached its max zoom, it may not respond because no additional adjustments can be made

Camera  
Avaya HC020

Microphone  
Avaya HC020

Connection  
HDMI

## Microphone not working?

### 1. Ensure the sound system is on

On the back left the "On/Off" button should be depressed

### 2. Ensure the microphone cable is connected to Mic 1

If necessary turn the level control up

- Change camera and audio settings
- Step-by-step software instructions
- Troubleshoot classroom technology

[www.elon.edu/ClassTechGuide](http://www.elon.edu/ClassTechGuide)

Report an Issue

[www.elon.edu/ITsupport](http://www.elon.edu/ITsupport) | (336) 278-5200